# **GENERAL SERVICE INFORMATION**

# SYNCHRONIZATION AND LINKAGE ADJUSTMENTS

To ensure consistent engine idling and smooth operation throughout the full RPM range, it is important that each procedure be performed exactly as written and in the following sequence:

- 1 st Ignition Timing Adjustment
- 2nd Carburetor Synchronization
- 3rd Oil Pump Aperture Adjustment

## **⚠ WARNING**

Before beginning procedures, disable the ignition system to prevent accidental engine startup.

## **CAUTION**

The following applies to all engines:


- Should the stopper lever <u>barely contact</u> the stopper, damage to the carburetor may occur when the throttle lever is in the full throttle position. Stopper lever should firmly contact the stopper.
- 2. If stopper lever is not in firm contact with the stopper, but a small gap is present, no damage should occur.
- 3. Carburetors #2, #3 and/or #4 will have a gap between throttle stop and stopper when Carburetor #1 is properly adjusted.
- 4. After fine adjustment, stopper bolt lengths may differ from pre-adjustment settings.

#### NOTE

Adjustment lengths for links (1), stoppers (2), and carburetor link rods (3) are measured as shown.

#### NOTE

The seam at the mating surfaces of the crankcase halves is the alignment point for all ignition timing degree measurements.




3-/ 4-Cylinder 2-25


### **Ignition Timing Adjustment**

#### Models 40D / 50D

1. Pre-set ignition timing link (1) and throttle link (2) to specified lengths.

	Length (approximately)	
Model	Ignition Timing Link 1	Throttle Link (2)
40D	5.04 in [129 mm]	3.86 in [99 mm]
50D	5.04 in [129 mm]	3.86 in [99 mm]





Model	Ignition Timing - Full Throttle
40D	BTDC 18° ± 1°
50D	BTDC 24° ± 1°

#### **NOTE**


Align flat surface (4) of crankcase mold boss with calibration of set ring.

4. After adjusting at maximum engine speed, set the advancer arm (3) to minimum engine speed and adjust the ignition to ATDC  $3^{\circ} \pm 1^{\circ}$  using the low speed side stopper (5).


Model	Ignition Timing - Throttle Closed
40D	ATDC 3° ± 1°
50D	ATDC 3° ± 1°

#### **NOTE**


Align flat surface (4) of crankcase mold boss with calibration marks on set ring.




T1069




T1070





T1072




# **GENERAL SERVICE INFORMATION**


## **Ignition Timing Adjustment**

#### Models 40D2 / 50D2

7 1. Adjust ignition timing link (1) and throttle link (2) to specified length.

	Length	
Model	Ignition Timing Link 1	Throttle Link (2)
40D2	3.98 in [101 mm]	4.53 in [115 mm]
50D2	3.86 in [98 mm]	4.53 in [115 mm]





Model	Ignition Timing - Full Throttle
40D2	BTDC 18° ± 1°
50D2	BTDC 20° ± 1°


#### **NOTE**

- **9** Align flat surface **(4)** of crankcase mold boss with calibration marks on set ring.
- 4. Place advancer arm (3) in the minimum speed position (throttle fully closed) and adjust low speed side stopper (5) so ignition timing matches the following specifications:


Model	Ignition Timing - Throttle Closed
40D2	ATDC 3° ± 1°
50D2	ATDC 3° ± 1°

#### **NOTE**


Align flat surface (4) of crankcase mold boss with calibration marks on set ring.




T1069




T1070





T1072



3-/ 4-Cylinder 2–27