

FIG. 18 CONTROL 1

FIG. 18 CONTROL 1




FIG. 18 CONTROL 1

FIG. 19 CONTROL 2

COMMANDE 2

REF. NO.	PART NO. NO. PIECES	DESCRIPTION	F6MH	F8MH	SAV	F8W	REMARKS REMARQUES
1	68T-48531-00	BRACKET, REMOTE CONTROL 1 ETRIER 1, COMMANDE A DISTANCE				1	
2	682-48538-50	CLAMP, CABLE 1 COLLIER				2	
3	91690-30012	PIN, SPRING GOUPILE, ELASTIQUE				2	
4	97095-06012	BOLT BOULON				2	
5	92995-06600	WASHER RONDELLE				2	
6	95380-06600	NUT, HEXAGON ECROU				2	
7	93210-12327	O-RING JOINT TORIQUE				1	
8	97095-05016	BOLT BOULON				1	
9	92995-05600	WASHER RONDELLE				1	
10	68T-44121-01	LEVER, SHIFT ROD LEVIER, TIGE D'INVERSION				1	
11	6G1-41662-01-94	BRACKET SUPPORT				2	
12	90109-06M81	BOLT BOULON				2	
13	90464-10M60	CLAMP BRIDE				1	
14	91690-30014	PIN, SPRING GOUPILE, ELASTIQUE				1	
15	65W-44116-00	SPRING RESSORT				1	
16	68R-44114-00	STOPPER PLAQUETTE				1	
17	90109-06M86	BOLT BOULON				1	
18	68T-44143-00	ROD, SHIFT TIGE D'EMBRAYAGE				1	S
19	90468-18001	CLIP JONG				1	
20	90170-06015	NUT ECROU				1	
21	95380-06700	NUT ECROU				1	
22	68T-44111-10	HANDLE, GEAR SHIFT POIGNEE, LEVIER D'EMBRAYAGE				1	
23	663-48344-00	CABLE END, REMOTE CONTROL CHAPE CABLE				1	
24	90468-18008	CLIP JONG				1	
25	68T-41638-00	PULLEY POULIE				1	
26	68T-41283-00	LEVER, FREE ACCEL. LEVIER				1	
27	90387-06M59	COLLAR COLLERETTE				1	




68R0300-0190

FIG. 19 CONTROL 2

COMMANDE 2

REF. NO.	PART NO. NO. PIECES	DESCRIPTION	F6MH	F8MH	SAV	F8W	REMARKS REMARQUES
28	68T-41211-00	LINK, ACCEL.				1	
29	68T-14497-00	BIELLETTA; ACCELERATION STAY, THROTTLE WIRE SUPPORT DE BOISSEAU				1	
30	90201-06M62	WASHER, PLATE RONDELLE, PLATE				1	
31	97095-06045	BOLT				1	
32	92995-06600	BOULON				1	
33	97095-06012	WASHER				1	
34	92995-06600	RONDELLE				1	
35	661-41262-02	BOLT				1	
36	647-14395-60	BOULON				1	
37	663-48344-00	WASHER				1	
38	90468-18008	RONDELLE				1	
		JOINT, CHOKE LEVER RACCORD, LEVIER DE STARTER					
		CAP, OVERFLOW PIPE COUVRE DE DURITE REFOULEMENT					
		CABLE END, REMOTE CONTROL CHAPE, CABLE					
		CLIP					
		JONG					




68R0300-0190

FIG. 20 REMOTE CONTROL ATTACHMENT

COMMANDE A DISTANCE

REF. NO.	PART NO. NO. PIECES	DESCRIPTION	F6MH	SA	F8W	REMARKS
1	68R-48501-00	REMOTE CONT. ATTACHMENT ASSY. COMMANDE A DISTANCE (KIT)	1	1		AP
2	68T-48531-00	BRACKET, REMOTE CONTROL 1 .ETRIER 1, COMMANDE A DISTANCE	1	1		
3	682-48538-50	CLAMP, CABLE 1 .COLLIER	2	2		
4	91690-30012	PIN, SPRING .GOUPILE, ELASTIQUE	2	2		
5	97095-06012	BOLT .BOULON	2	2		
6	92995-06600	WASHER .RONDELLE	2	2		
7	95380-06600	NUT, HEXAGON .ECROU	2	2		
8	68T-44111-10	HANDLE, GEAR SHIFT .POIGNEE, LEVIER D'EMBRAYAGE	1	1		
9	93210-12327	O-RING .JOINT TORIQUE	1	1		
10	97095-05016	BOLT .BOULON	1	1		
11	92995-05600	WASHER .RONDELLE	1	1		
12	663-48344-00	CABLE END, REMOTE CONTROL .CHAPE CABLE	1	1		
13	90468-18008	CLIP .JONG	1	1		
14	663-48344-00	CABLE END, REMOTE CONTROL .CHAPE CABLE	1	1		
15	90468-18008	CLIP .JONG	1	1		
16	68T-42725-10	GROMMET .PASSE-FIL	1	1		



68R0010-1190