



17

ELECTRICAL WIRING DIAGRAM

TYPE: F, EF, EPO, EFTO





Part name table of Electrical Wiring Diagram (M40D, M50D)

No.	Part name	No.	Part name	No.	Part name
1	Pulser coil ass'y	18	Battery cord	35	Lead wire, meter
2	Alternator	19	Cord Ass'y A	36	Oil lamp
3	Exciter coil	20	Cord Ass'y B	37	Pilot lamp
4	C.D. Unit	21	Cord Ass'y C	38	Speedometer
5	Ignition coil	22	PTT switch B	39	Water pressure meter
6	Rectifier complete	23	Starter cord	40	Hourmeter
7	Starter motor	24	Cord A, Solenoid switch	41	Voltmeter
8	Starter solenoid	25	Cord B, Solenoid switch	42	Water temp. meter
9	Power trim and tilt	26	Cord C, Solenoid switch	43	Fuel meter
10	Solenoid switch A, PTT	27	Battery (to be supplied locally)	44	Fuel gauge sensor unit
11	Solenoid switch B, PTT	28	Main switch	45	Cord, fuel meter
12	Trim sender	29	Safety switch	46	Lead wire, water temp. meter
13	Fuse wire	30	Over heat buzzer	47	Meter lamp switch
14	Choke solenoid	31	Neutral switch	48	Asist cord (Black)
15	Oil bell sensor	32	PTT switch	49	Asist cord (Red)
16	Over heat sensor	33	Tachmeter	50	Asist cord (Blue)
17	Sender, water temp.	34	Trim meter		

Color of cord

B	Black
Br	Brown
G	Green
L	Blue
Lg	Light green
Or	Orange
P	Pink
R	Red
Sb	Sky blue
W	White
Y	Yellow

18

POWER TRIM AND TILT

(1) System diagram

