




Fig. 22 UPPER CASING

Ref. No.	Part No.	Description		Remarks
1	66T-41137-00-94	GUIDE, EXHAUST	1	
2	90119-08M79	BOLT, WITH WASHER	2	
3	93606-12019	PIN, DOWEL	2	
4	66T-41131-00-5B	MANIFOLD, EXT. 1	1	S
	66T-41131-10-5B	MANIFOLD, EXT. 1	1	L/X
5	66T-41133-A0	GASKET, EXHAUST MANIFOLD 1	1	
6	97075-08030	BOLT	2	
7	92995-08600	WASHER	2	
8	66T-45111-00-4D	CASING, UPPER	1	S
	66T-45111-10-4D	CASING, UPPER	1	L/X
9	63D-45155-00	CAP	1	
10	97575-08545	BOLT, WITH WASHER	3	
11	90119-08M79	BOLT, WITH WASHER	2	
12	66T-45114-A0	GASKET, UPPER CASING	1	
13	66T-45113-A0	GASKET, UPPER CASING	1	
14	93606-12019	PIN, DOWEL	2	
15	90119-08M42	BOLT, WITH WASHER	6	
16	679-45318-00	BUSHING, DRIVE SHAFT	1	L/X
17	93420-30042	CIRCLIP	1	L/X
18	66T-45211-00-4D	EXTENSION	1	X
19	93606-12019	PIN, DOWEL	2	X
20	90116-10M23	BOLT, STUD	4	X
21	95380-10600	NUT	4	X
22	92990-10100	WASHER, SPRING	4	X
23	92990-10600	WASHER, PLATE	4	X