



LOWER UNIT

LOWER UNIT PREPARATION FOR REMOVAL

- Drain the gear oil.

* : For long models-with upper casing.

