


**ELECTRICAL COMPONENTS (PRE-MIXED AND 115BETO MODELS)  
(Port view)**




- ① Fuse (20A)
- ② Starter relay
- ③ Power trim and tilt relay
- ④ Starter motor

- A** To fuel enrichment valve
- B** To battery
- C** To CDI unit and 10P coupler
- D** To power trim and tilt motor
- E** To trim sensor
- F** To trim meter

- B** : Black
- Br** : Brown
- Lg** : Light green
- R** : Red
- Sb** : Sky blue

**(Starboard view)**




8050

- ① Rectifier/regulator
- ② Thermo switch
- ③ Lighting coil lead
- ④ Charge coil lead
- ⑤ Pulser coil lead
- ⑥ Fuel enrichment valve
- ⑦ Shift cable
- ⑧ Throttle cable

- A** To CDI unit
- B** To thermo switch
- C** To starter assembly
- D** To wire harness
- E** To trim sensor
- F** To starter relay and starter motor
- G** To battery
- H** To remote control
- I** To trim meter

- B** : Black
- G** : Green
- L** : Blue
- O** : Orange
- P** : Pink
- R** : Red
- G/W** : Green/white
- Gy/B** : Gray/black

(Aft view)



- ① Thermo switch
- ② Ignition coil
- ③ CDI unit
- ④ Charge coil lead
- ⑤ Pulser coil lead

- A** To relay assembly
- B** To charge coil
- C** To wire harness
- D** To 10P coupler
- E** To pulser coil

- B** : Black
- P** : Pink
- B/W** : Black/white
- Gy/B** : Gray/black